


HOW TO CHOOSE THE RIGHT SIZE WESTLAND BIMINI TOP



1) DETERMINE LENGTH

Determine the amount of coverage you want from your Bimini. Length options are 60", 66", 72" and 96".

2) DETERMINE MOUNTING POINTS

Select a point on each side of the boat that will be the middle of the Bimini based on the desired length. These are the mounting points and where you will attach your Bimini to your boat.

The 90° deck mounts included with the Bimini are designed to mount on a relatively flat horizontal surface. However, optional mounts are available for vertical side mounting or rail mounting.

3) DETERMINE WIDTH

Measure the distance between the mounting points on each side of the boat. Width options are in 6" increments

4) DETERMINE HEIGHT

A = From the centerline of the floor of the boat, determine how much headroom you want for the Bimini. It is recommended to at least allow for 72" of standing height, but select what is best for you and those using your boat.

B = Measure the distance from floor to the mounting point on the sides of the boat.

C = A - B = Bimini height to purchase

5) SELECT BIMINI

Choose your Bimini by visiting

<https://westlandcovers.com/shop-by-bimini-dimensions.html>

All Biminis include installation instructions. Westland Industries is not responsible for any injuries to persons or damages to the boat during assembly and installation of its Biminis. Installation of Biminis may void a boat warranty, advise customers to check with a dealer. Replace any worn parts to increase the life of the product.